



KC500 Wedge Door Seal Weather Strip Installation Instructions and Warranty



You will need: Measuring tape, a hacksaw, and a drill

Step 1:

Carefully measure the top width of the doorstop.



Step 2:

Cut, if necessary, the 36 in. top section and install with the door *closed* using the included screws. The foam gasket side should make light contact with the door. The slotted screw holes allow for adjustment. Tighten screws for a secure fit.



Step 3:

Repeat this process for the left and right sides, measuring from the top of the doorstop to the threshold of the floor.



Product Warranty:

This product is warranted to be free from defects in material and workmanship for one year. For replacement product, contact customercare@amconservationgroup.com and have proof of purchase available. Manufacture may require original product to be shipped back for evaluation and/or pictures of defective product to be provided.