



INSTRUCTIONS FOR USE

INSTRUCCIONES DE USO

DOOR BOTTOM

Slide-On Vinyl

Installation:

1. Measure width of door.
2. Shorten vinyl door bottom if needed.
3. Slide door bottom on the door so the strips rest on the threshold with the holes on the inside.
4. Mark hole locations, then drill and screw into place.



Vinilo instala deslizando

FONDO PARA PUERTAS

Instalación:

1. Mida el ancho de la puerta.
2. Corte el fondo de vinilo si es necesario.
3. Deslice el fondo en la puerta de manera que las tiras descansen sobre el umbral con los agujeros al interior.
4. Marque los agujeros, taladre y atornille en su lugar.

TOOLS NEEDED:

HERRAMIENTAS NECESARIAS:



Follow Us @FrostKing
or www.frostking.com



Thermwell Products Co., Inc.
Mahwah NJ 07430 | Sparks NV 89431

Need help or information
about any Frost King product?

Call **1-877-FROST 20**
3 7 6 7 8

For videos, instructions, hints and tips
visit www.frostking.com/instructions